

Important: Only use the mains power adaptor, cables and rechargeable batteries supplied in this box, or this product may not work. Any replacement rechargeable batteries must be of the same type. BT accepts no responsibility for damage caused to your BT Studio 4500 Plus by using any other type of batteries.



Check box contents


BT Studio 4500 Plus User Guide



- 1 Plug in**
- 2 Charge**
- 3 Go!**

Setting up is easy. Just follow the simple steps in this guide. If you need further assistance, please visit our website www.bt.com/producthelp to view our advanced user guide or call our helpdesk on **0800 218 2182***

* Calls made from within the UK mainland network are free. Mobile and International call costs may vary.



1 Plug in

2 Charge

- 1 Remove the protective film from the handset screen and the base lens and activate the batteries by pulling the plastic tab away from the back of the handset.
- 2 Place the handset on the base to charge.
- 3 After 24 hours, plug the telephone line cord into the telephone wall socket.

Important: Charge the handset batteries for 24 hours or your phone may not work.



Set up your additional handsets (multi-packs only)

- 1 For each additional handset: plug the mains power adaptor (item code 048610) into the socket on the back of the charger, secure the cable behind the retaining clip and plug the other end into the mains wall socket and switch the power on.
- 2 Remove the protective film from the handset screen and activate the batteries as shown above.
- 3 Place the handset on the charger to charge for 24 hours.

If you ever need to remove the batteries, simply slide open the battery compartment cover and using the finger grip the batteries and pull them out.

Your BT Studio 4500 Plus is now ready for use.

Please turn over

General information

For information on safety instructions, cleaning, technical information or connecting to a switchboard, please refer to the 'General Information' section in the full user guide at www.bt.com/producthelp

Guarantee

Your BT Studio 4500 Plus is guaranteed for a period of 12 months from the date of purchase. Subject to the terms listed below, the guarantee will provide for the repair of, or at BT's or its agent's discretion the option to replace the BT Studio 4500 Plus, or any component thereof, (other than batteries), which is identified as faulty or below standard, or as a result of inferior workmanship or materials. Products over 28 days old from the date of purchase may be replaced with a refurbished or repaired product.

The conditions of this guarantee are:

- The guarantee shall only apply to defects that occur within the 12 month guarantee period.
- Proof of purchase is required.
- The equipment is returned to BT or its agent as instructed.

This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.

This guarantee does not affect your statutory rights. For further information within and outside the 12 month guarantee, please refer to the full user guide at www.bt.com/producthelp

Product disposal instructions

The symbol shown here and on the product means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life.

The Waste of Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the increasing landfill.

Product disposal instructions for residential users
When you have no further use for it, please remove any batteries and dispose of them and the product as per your local authority's recycling processes. For more information please contact your local authority or the retailer where the product was purchased.

Product disposal instructions for business users
Business users should contact their suppliers and check the terms and conditions of the purchase contract and ensure that this product is not mixed with other commercial waste for disposal.

Warning

This equipment is not designed for making emergency telephone calls when the power fails. Alternative arrangements should be made for access to emergency services.

R&TTE Directive & Declaration of Conformity

This product is intended for use within the UK for connection to the public telephone network and compatible switchboards.

This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive (1999/5/EC).

For a copy of the Declaration of Conformity please refer to www.bt.com/producthelp



Working together, supporting energy saving products

BT & British Gas have joined forces to help our customers find new ways to save energy around the home, so we can all do our bit for the environment & save money too!

BT is a sustainability leader

To find out how we're making our products greener visit

bt.com/betterworld/products

Offices worldwide

The services described in this publication are subject to availability and may be modified from time to time. Services and equipment are supplied subject to British Telecommunications plc's respective standard conditions of contract. Nothing in this publication forms any part of a contract.

© British Telecommunications plc 2010. Registered Office: 81 Newgate Street, London EC1A 7AJ. Registered in England No. 1800000.

Designed and produced by The Art & Design Partnership Ltd.

Printed in China / Issue 1 / ADP08-10




Your phone

Handset



The answer machine handset controls on buttons **2**, **4**, **5** and **6** will only work when a message is being played on the handset.

Base



3 Go!

Set time and date

Press **Menu** to open the main menu.

Press **Call** to scroll to HS SETTINGS and press **✓** soft key. DATE & TIME is displayed, press **✓**.

Press **Call** to SET TIME and press **✓** soft key. Enter 2 digits for the hour and 2 for the minute using the 24hr format and press **✓** soft key. You will hear a confirmation tone.

Press **Call**, SET DATE is displayed. Press **✓**. Enter the day, month and year using the dd-mm-yy format and press **✓**. You will hear a confirmation tone.

Making calls

Press **Call** then dial the phone number. Press **End call** to end the call.

Answering calls

If you have subscribed to Caller Display, the caller's details will be displayed before you answer (see below and also the full user guide online at www.bt.com/producthelp for details).

Lift the handset from the base or charger to answer incoming calls. If the handset is **not** on the base or charger, press **Call**.

Secrecy

Press the **X** soft key during a call to activate secrecy mode, if you want to prevent the caller hearing anything from your end. Press the **X** soft key again to resume your call.

Redial (up to last 10 numbers called)

Press **Redial** to open the list of most recently dialled numbers. Press **Redial** or **Call** to scroll through the list.

Press **Call** to redial the number displayed or press **✓** to access the options menu.

Phonebook

Storing new phonebook entries (up to 50)

Press **Open phonebook** to open the phonebook. The first entry (or LIST EMPTY) is displayed.

Press the **✓** left soft key, ADD is displayed. press **✓**. NAME is displayed. Using the letters on the keypad, enter the name, then press **✓**. You may need to press the same button a few times until the letter you want is displayed. For example, press **2** once for A, or twice for B. NUMBER is displayed, enter the phone number for the entry and press **✓**. If you make a mistake, press **X** to delete the last digit or letter entered.

Press **Redial** or **Call** to select a ringtone you want to be played when this caller rings you and press **✓** to confirm. Press **↩** to return to standby.

Dialling a phonebook entry

Press **Open phonebook**. Scroll **Redial** or **Call** to the entry you want. Press **Call** to dial.

Or, search alphabetically using the keypad to enter the first letter of the name you want then scroll **Redial** or **Call** to the exact entry and press **Call** to dial.

Caller Display and the Call list

You must subscribe to a Caller Display service for this feature to work. Your network provider may charge you for this service.

View and dial from the Call list

Press **Call**, then **Redial** or **Call** to scroll through the last 40 incoming calls.

The **Call** indicates new missed calls. The number of New Calls to the handset is shown on the standby screen until they have all been viewed in the calls list.

The **>** icon is displayed when the phone number is too long to be fully shown on the screen. Press **#** to allow you to scroll through the rest of the number.

Press **Call** to dial the number displayed.

Copy a Call list number to the phonebook

Press **Call**, then **Redial** or **Call** to the entry you want and press **✓**.

Press **Call** until STORE NUMBER is displayed and then press **✓**. NAME is displayed. Enter a name using the keypad and press **✓**. The number is displayed, press **✓** to confirm.

You will hear Melody 1 played, press **Redial** or **Call** to choose a ringtone you want to be played when this caller rings you and then press **✓**.

Answering machine

Your answering machine is on and ready to record messages. The controls are shown in the base diagram to the bottom left and the features can also be accessed via the handset ANSW MACHINE menu.

Recording your own outgoing message

Press **Menu**. The display shows ANSW MACHINE, press **✓**.

Press **Call** to scroll to ANSW SETTINGS and press **✓**.

Press **Call** to scroll to OUTGOING MSG and press **✓**.

Press **Redial** or **Call** to select either ANSW & RECORD or ANSWER ONLY and press **✓**.

Press **Call** to scroll to RECORD MSG and press **✓** to record your message.

When prompted, speak your message into the handset. When finished press **✓**. Your message will be played back to you. Press **X** if you want to delete the message.

Set the answer delay

To set the number of rings that are played before the answer machine picks up:

Press **Menu**. The display shows ANSW MACHINE, press **✓**.

Press **Call** to scroll to ANSW SETTINGS and press **✓**.



Press **Call** to scroll to ANSWER DELAY and press **✓**.

Press **Redial** or **Call** to select the number of rings before the answer machine answers: 2-9 rings or time saver and press **✓**.

For detailed instructions on all the answering machine features see the full user guide online at www.bt.com/producthelp

Help

Most problems can be fixed with a few simple checks.

Problem	Solution
No dial tone	Only use the cables and batteries supplied. Make sure both the mains power adaptor cable and telephone line cord are plugged into the correct sockets.
Poor speech quality	Make sure the product is not located too close to other electrical appliances. This can also help improve the handset range from the base.
 Battery icon flashing and scrolling digits	The battery charge is very low. Make sure you charge the batteries for 24 hours before use to ensure maximum battery performance.
Using broadband on the same phone line?	Make sure you plug the phone into the wall socket via an ADSL microfilter (not supplied), otherwise you may have problems with this product and your broadband service. 
Answer machine not answering calls	Check the answer machine is on and set to Answer & Record. Also check that the ring delay is set to answer before any voicemail service (e.g. 1571) on the line.

Find out more

- New Frequently Asked Questions available at www.bt.com/producthelp
- If you need more detailed instructions, a full user guide is available to download from www.bt.com/producthelp
- If you cannot find the answer to your problem in the full online user guide, then please call our free Helpline on 0800 218 2182*. Our dedicated advisors are more likely to be able to help you than the retailer where you made your purchase.
- This document is also available in other formats, such as Large print, Braille and Audio CD. If you would like a copy, please call 0800 218 2182*.